

Installation Instructions

For 10865 & 10866 Motors

Technical Assistance 800-678-9888 • M-F 8AM - 5PM EST.



WARNING!

To prevent electric shock, personal injury, or death, turn off the electric power at the disconnect or main service panel prior to making any electrical connections.

Connections:

Red Jumper: Voltage
White Jumper: Rotation

Brown/White Plug: For Optional Hand Held Tuner

(MARS No. 08502)

White: Neutral / L2
Green/Yellow: Ground

Multi Color: (5) 115/230V Speed/Torque Taps

Suggested Tap Selections:

No. 10865 1/3 - 1/2 HP No. 10866 3/4 - 1 HP Tap 1 Low Constant Fan Constant Fan 2 Med Low 1/3 HP Heat 3/4 HP Heat 3/4 HP Cool 3 Med 1/3 HP Cool 4 Med High 1/2 HP Heat 1 HP Heat 5 High 1/2 HP Cool 1 HP Cool

Connection Notes:

The Azure motor has 5 speed/torque taps. The table above offers suggested tap selections. Due to a variety of variables, these selections may need to be altered either higher or lower. Use MARS No. 08502 hand held tuner to manually adjust any of the speed/torque taps for optimum CFM flexibility especially in multi-speed applications (MARS No. 08502 is required). Insulate and tie off any unused taps. Do not allow taps to contact ground.

98694 1/20

©2020 MOTORS & ARMATURES, Inc. All rights reserved. MARS is a registered trademark of Motors & Armatures, Inc.

www.marsdelivers-contractors.com





Installation Instructions

For 10865 & 10866 Motors

Technical Assistance 800-678-9888 • M-F 8AM - 5PM EST.



WARNING!

To prevent electric shock, personal injury, or death, turn off the electric power at the disconnect or main service panel prior to making any electrical connections.

Connections:

Red Jumper: Voltage
White Jumper: Rotation

Brown/White Plug: For Optional Hand Held Tuner

(MARS No. 08502)

White: Neutral / L2
Green/Yellow: Ground

Multi Color: (5) 115/230V Speed/Torque Taps

Suggested Tap Selections:

No. 10865 1/3 - 1/2 HP No. 10866 3/4 - 1 HP Tap 1 Low Constant Fan Constant Fan 3/4 HP Heat 2 Med Low 1/3 HP Heat 1/3 HP Cool 3/4 HP Cool 3 Med 1/2 HP Heat 1 HP Heat 4 Med High 5 High 1/2 HP Cool 1 HP Cool

Connection Notes:

The Azure motor has 5 speed/torque taps. The table above offers suggested tap selections. Due to a variety of variables, these selections may need to be altered either higher or lower. Use MARS No. 08502 hand held tuner to manually adjust any of the speed/torque taps for optimum CFM flexibility especially in multi-speed applications (MARS No. 08502 is required). Insulate and tie off any unused taps. Do not allow taps to contact ground.

98694 1/20

